




Difficulty Level: ★ ★ ★ ★ ★

INSTALLATION MANUAL

Parts Included:	Qty.	Parts Included:	Qty.
(1) Piston	2	(11) Lower Mount	2
(2) Rod Guide	4	(12) Upper Mount	2
(3) Separator	2	(13) Cylinder	2
(4) Piston Retainer (#BRSHJR)	4	(14) Cylinder End Cap	2
(5) Oil Seal	4	(15) Spring	2
(6) Bump Stop	2	(16) Spring Retainer	2
(7) Cylinder seal	2	(17) Spring Preload Adjustor	2
(8) Friction Ring	2	(18) E-clip	4
(9) Pivot Ball (#BRW750310)	4	(19) Pivot Ball Tool (#BRT10053)	1
(10) Piston Rod	2		



1-3
Pay attention to cautions 1, 2 and 3.

